


PN58 INCREMENTAL	Ver. 2.0	Page 1/11
<ol> <li>PN58 Incremental Optical Encoder (Hollow Shaft)</li> <li>Introduction: PN58 with its unique through-shaft concentric locking device, double bearing large-aperture ultra-thin design, flexible spring plate installation, multiple electrical interfaces, and protection grade IP50, can solve the installation problems of low space limitations and slight axial movement of the motor shaft.</li> </ol>	PN58-E	
<ul> <li>1.2 Feature:</li> <li>Encoder external diameter Ø58mm, thickness min 14mm, diameter of shaft up to Ø24mm;</li> <li>Adopt non-contact photoelectric principle;</li> <li>Reverse polarity protection;</li> <li>Short circuit protection;</li> <li>Multiple electrical interfaces available;</li> <li>Resolution per turn up to 5000PPR.</li> </ul> 1.3 Application: Servo motor, robot and automation control fields.	PN58-F	
<ul> <li>1.4 Connection: <ul> <li>Radial socket (8P &amp; 14P)</li> <li>Radial cable (standard length 1.0M)</li> </ul> </li> <li>1.5 Protection: <ul> <li>IP50</li> </ul> </li> <li>1.6 Weight: <ul> <li>About 90g</li> </ul> </li> </ul>	PN58-J	

### 2. Model Selection Guide

2.1 Model composition(select parameters)




2.2 Note

- 1. Z signal is low level active.
- 2. Z signal is high level active.
- 8. Blank means IP50, cable length is 1.0M, if need to change the length C+number, the longest is 100M (expressed by C100). For the specific length of use, pls refer to page P2 -P3 of the provision of output circuit.

www.shhxgd.com fang@shhxgd.com Tel: 86-21-54613487 We reserve the final interpretation right of this specifications, subject to change without notice .

## 3. Output Method


3.1 Incremental signal



www.shhxgd.com fang@shhxgd.com Tel: 86-21-54613487 We reserve the final interpretation right of this specifications, subject to change without notice .

Ver. 2.0 Page 2/1

3.2 For servo motor(with UVW)



www.shhxgd.com fang@shhxgd.com Tel: 86-21-54613487 We reserve the final interpretation right of this specifications, subject to change without notice

No: 01100116

Ver. 2.0 Page 3/1

4. Electrical Parameter

Parameter Output Item			OC	Voltage	Push-pull	TTL	TTL (Less wiring type)	HTL				
Sup	ply volta	ge	DC+5V±5%; DC8\	/-30V±5%		DC+5V±5%	DC8-30V±5%					
Cor	rent 100mA Max				120mA Max							
Allo	Nlowable ripple ≤3%rms											
Top freq	respons uency	Э	100KHz			300KHz		500KHz				
	Output	Input	≤30mA Load resistance		≤30mA	≤±20mA		<150mA				
acity	current	Output	_	2.2K	≤10mA			≤±50mA				
cap	Output	"H"	_	_	≥[ (Supply voltage) -2.5V]	≥2.5V		≥Vcc-3 VDC				
Output capacity	voltage	"L"	≤0.4V	≤0.7V(less than 20mÀ)	≤0.4V(30mA)	≤0.5V	≤ 1V Vpc					
0	Load vol	tage	≤DC30V	_	•	-						
Rise	Rise & Fall time Less than 2us(cable length: 2m)					Less than 1us(Cable length: 2m)						
Insu	lation str	ength	AC500V 60s			·						
	lation stance		10MΩ									
Mar	k to space	e ratio	45% to 55%									
Rev prot	erse pola ection	arity	<ul> <li></li> </ul>									
Sho	rt-circuit ection		_		v0							
Pha	se shift		90°±10° ( frequency in low speed)									
betv	veen A &	В	90°±20° (frequency	/ in high speed)								
Dela time	ay motion		_				510±220ms	-				
GNE			Not connect to enco	oder								

• Short-circuit to another channel or GND permitted for max.30s.

Phase A.B.Z are back of phase U.V.W when power on.

www.shhxgd.com fang@shhxgd.com Tel: 86-21-54613487 We reserve the final interpretation right of this specifications, subject to change without notice

Ver. 2.0 Page 4/1

Ver. 2.0 Page 5/11

# 5. Mechanical Specification

Diameter of shaft	Ø14mm; Ø15mm; Ø19mm; Ø24mm(optional)
Starting torque	Less than 9.8×10 <sup>-3</sup> N⋅m
Inertia moment	Less than 6.5×10 <sup>-6</sup> kg·m²
Shaft load	Radial 30N; Axial 10N
Slew speed	≤5000 rpm
Bearing Life	1.5X10 <sup>9</sup> revs at rated load(100000hrs at 2500RPM)
Material	Base: Die cast aluminum
Weight	About 90g

# 6. Environmental Parameter

Environmental temperature	Operating:-20~+85°C(repeatable winding cable: -10°C); Storage:-20~+90°C
Environmental humidity	Operating and storage: 35~85%RH(noncondensing)
Vibration(Endurance)	Amplitude 0.75mm,5~55Hz,2h for X,Y,Z direction individually
Shock(Endurance)	490m/s <sup>2</sup> 11ms three times for X,Y,Z direction individually
Protection	IP50

## HENGXIANG /// Encoder

INCREMENTAL

# 7. Wiring Table

7.1 OC / Voltage

**PN58** 

			Signal				Supply voltage	
Socket pin No.	1	2	3	4	5	6	7	8
Wire color	White	-	Green	-	Yellow	-	Red	Black
Function	А	-	В	-	Z	-	Up	0V

#### 7.2 TTL / HTL / Push-pull / Less wiring type

			Sig	nal			Supply voltage		
Socket pin No.	1	1 2		3 4		6	7	8	
Wire color	White	White/BK	Green Green/BK		Yellow	Yellow/BK	Red	Black	
Function	A+ $(U+)^*$	<b>A-</b> (U-)*	B+ (∀+)* B- (∀-)*		<b>Z+</b> (₩+)*	Z- (₩-)*	Up	0V	
Twisted-paired cable									

\* For the functional status in less wiring mode, refer to the functional mode wiring table for output circuit on page3.

#### 7.3 For servo motor

		Signal									Supply voltage			
Socket pin No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14
Wire color	Blue	Blue/Bk	Grey	Grey/Bk	Pink	Pink/Bk	Yellow	Yellow/BK	Green	Green/BK	White	White/BK	Black	Red
Function	U+	U-	V+	V-	W+	W-	Z+	Z-	B+	B-	A+	A-	0V	Up
Twisted- paired cable	ed De													

Up=Supply voltage.


Shield wire is not connected to the internal circuit of encoder.

Ver. 2.0 Page 6/1


No: 01100116

### 8. Socket & Cable

#### 8.1 Socket pin definition



#### 8.2 Radial Cable Schematic




#### Unit: mm

www.shhxgd.com fang@shhxgd.com Tel: 86-21-54613487 We reserve the final interpretation right of this specifications, subject to change without notice

No: 01100116

Ver. 2.0 Page 7/1



www.shhxgd.com fang@shhxgd.com Tel: 86-21-54613487 We reserve the final interpretation right of this specifications, subject to change without notice

R3 = Radial cable(standard length 1M).

## No: 01100116

Ver. 2.0 Page 9/11

## 10. Assembly Steps for Servo Motor Encoder


10.1 Encoder installation and zero position alignment with U.V.W

#### Step 1

- a. Before installing the encoder, first to confirm the starting zero position of the motor and lock it tightly to ensure that the motor shaft is not moving until the encoder is finished installation,otherwise the encoder and the motor's zero position cannot be aligned.
- b. Put the encoder (2) directly on the motor shaft and gently push it to the motor platform by hand.
- c. Screwed the two M3\*15 bolts (3) at the same time, but do not tighten, just enough to rotate the encoder by hand.

#### Note:

Please refer to page 8 for the matching tolerance of the encoder shaft sleeve and the motor shaft.




#### Step 2

- Fix the spanner (A) on the slot of the encoder shaft sleeve (outer ring) and then use the spanner (B) to tighten the lock nut (recommended tightening force is 13-16N.m).
- b. Pls refer to the socket connection table on page 6-7 for connection, power on after checking all are correct, please confirm again that the motor is in the zero locked state, and then turn the encoder (2) left and right by hand, observe the LED on the encoder, when it is on,the zero signal is aligned, then tighten the two M3\*15 bolts (3) and keep the LED on.

#### Note:

- \*. The red mark on the shaft sleeve is always aligned with the LED indicator.
- \*. After making sure that the lock nut has been tightened, put thread glue on the inner thread of the slot to prevent the screw from loosening.
- \*. Because the width of the zero signal is relatively narrow, it is easy to cause displacement during the tightening process and the LED may not light up. please be patient to debug or use other testing equipments as auxiliary observation.



### HENGXIANG /// Encoder

PN58 INCREMENTAL



No: 01100116


10.2 Incremental encoder installation steps

#### Step 1

Put the encoder (2) directly on the motor (1) shaft and gently push it to the motor platform, then screw in two M3\*15 bolts (3) and tighten them at the same time.

Note:

Please refer to page 8 for the matching tolerance of the encoder shaft sleeve and the motor shaft.



Step 2


Fix the spanner (A) on the slot of the encoder shaft sleeve (outer ring) and then use the spanner (B) to tighten the lock nut. (recommended tightening force is 13-16N.m).

Note:

\*. The red mark on the shaft sleeve is aligned with the LED indicator light for the zero primary position.

When the power is turned on and the LED light is on, it is the precise zero position.

\* After making sure that the lock nut has been tightened, put thread glue on the inner thread of the slot to prevent the screw from loosening.



www.shhxgd.com fang@shhxgd.com Tel: 86-21-54613487 We reserve the final interpretation right of this specifications, subject to change without notice .



# Ver. 2.0 Page 11/11

## 11 Caution

11.1 About vibration

Vibration act on encoder always cause wrong pulse, so we should pay attention to working place. More pulse per revolution, narrower groovy spacing of grating, more effect to encoder by vibration, when rev is low or stop, vibration act on shaft or main body would cause grating vibrating, so encoder might make wrong pulse.

- 11.2 Caution for wiring
  - Use the encoder under the specified supply voltage. Please note that the supply voltage range may drop due to the wiring length.
  - Do not put the encoder wiring and other power lines through the same duct, and do not use them by bundling in parallel.
  - Please do not apply excessive force to the cable of encoder, or it will may be damaged.



2024.9.6